


图纸名称：思锐Y系列球碗球杯组件英文说明书

物料编号：EY75A2

尺寸：210×140mm


材质：华劲70G双胶/四色



Professional Photographic Equipment


INSTRUCTIONS

Y-75/Y-100 Series
Leveling Ball Set and Adapter Bowl




SIRUI Photographic Equipment Industry(Zhongshan) CO.,Ltd
Address: The Third Industrial District,Wuguishan Town,Zhongshan City,Guangdong,China
E-mail: info@sirui-photo.com http://www.sirui-photo.com http://www.zssirui.com
Tel: 0086-760-88897373 Fax: 0086-760-88207062 P.C: 528458
Service Hotline: (0086)400 830 2299

1. Know Leveling Ball Set and Adapter Bowl



2. Attaching method



1. Know Leveling Ball Set and Adapter Bowl

2. Replacing The Mounting Plate with an Adapter Bowl

To replace the Mounting Plate with the Adapter Bowl, loosen the Locking Clamp of the Tripod Mounting Platform with the allen key and remove the Mounting Plate. As shown in Figure 2, place the Adapter Bowl into the Mounting Platform and retighten the Locking Clamp. Place the Leveling Ball into the Adapter Bowl, align the Center Screw with the Screw hole in the Locking Control Grip and turn the Grip in a counter-clockwise direction until it is fairly tight. Do not over-tighten. To make sure the video head stays securely on the Leveling Ball (after you have attached the video head to the 3/8 Mounting Screw), screw the Locking Screws into the base of the video head (do not over-tighten).

You can level out the video head by loosening the Locking Control Grip and moving the head to the desired position.

Specifications are subject to change without notice.

Accessory Set Data Chart

	Maximum Load	Weight	Height	Diameter
	kg/lb	Kg/lb	mm/inch	mm/inch
Leveling Ball Set				
Y100B	1.10	0.5/1.10	39/1.5	106/4.17
Adapter Bowl				
Y100A	0.44	0.2/0.44	38/1.5	100/3.94
Leveling Ball Set				
Y75B	0.88	0.4/0.88	37/1.5	92/3.62
Adapter Bowl				
Y75A	0.22	0.1/0.22	29/1.1	91/3.58